

RW-MULTI8-FUJI

Lecteur avec port USB2 pour cartes Fujisoku 38-fiches

Description générale

Le lecteur RW-MULTI8-FUJI peut lire et programmer les cartes Fujisoku 38-fiches SRAM.

Ce lecteur se branche au PC par le port USB à l'aide du câble livré avec. L'alimentation électrique se fait par le port USB – pas d'adaptateur externe nécessaire.

Est également livré avec le CD-ROM contenant logiciel Windows nécessaire à la visualisation, édition, lecture et programmation des données.

Le RW-MULTI8-FUJI est uniquement livrable en lecteur externe avec boîtier métallique.

Applications typiques

- Sauvegarde des données contenues sur une carte Fujisoku
- Préparation des données avant le transfert sur la carte mémoire.

Installation

Le logiciel PC contenu sur le CD-ROM doit être installée avant de connecter le RW-MULTI8-FUJI au port USB de l'ordinateur.

La description complète de l'installation et de l'utilisation de ce lecteur de cartes Fujisoku se trouve dans le „User's Manual“.



Détails techniques

Physical	
Dimensions	118mm x 105mm x 32mm
Weight	215 g
Card Slot	Single, without ejector-button
Operating Temp.	0°C to 70°C

Card Support	
General	38-Pin Fujisoku and ITT-Canon memory cards
Writing	SRAM 32KByte up to 1Mbyte (For Flash or EPROM please contact supplier)
Reading	ROM, EPROM, FLASH, OTP

Electrical	
Supply	5VDC via USB Port
Power	0,5 VA
Data	USB

Platform & Operating-System	
Computer	IBM PC compatible with USB Port
Windows	Win98, Win98SE, WinME, Win2000, WinXP