

# **RW-MULTI8-FUJI**

## External Single-Slot 38-Pin Card Reader/Writer with USB2 Interface

#### **General Description**

The RW-MULTI8-FUJI drive can read from and write to Fujisoku 38-Pin SRAM memory cards.

The unit interfaces to a USB Port of a PC using the USB cable included.

The RW-MULTI8-FUJI draws the power it needs from the USB Port – no extra power-supply is needed.

The RW-MULTI8-FUJI kit includes a CD-ROM with Windows software for displaying, editing, reading and writing card data.

The compact and rugged reader/writer is supplied as a desktop unit in a robust metal housing.

### **Typical Applications**

- Backing up data from memory cards
- Enabling offline preparation of data for transferring to memory cards.

#### Installation

The PC Software, which is supplied on a CD-ROM, should be installed before plugging the RW-MULTI8-FUJI into the computer USB Port.

Full details of the installation and operation of the unit are given in the RW-MULTI8-FUJI User's Manual.



#### **Technical Features**

Physical	
Dimensions	118mm x 105mm x 32mm
Weight	215 g
Card Slot	Single, without ejector-button
Operating Temp.	0°C to 70°C

Card Support	
General	38-Pin Fujisoku and ITT- Canon memory cards
Writing	SRAM 32KByte up to 1Mbyte (For Flash or EPROM please contact supplier)
Reading	ROM, EPROM, FLASH, OTP

Electrical	
Supply	5VDC via USB Port
Power	0,5 VA
Data	USB

Platform & Operating-System	
Computer	IBM PC compatible with USB Port
Windows	Win98, Win98SE, WinME, Win2000, WinXP, Win7